

Description:

The Niagara™ Medium Duty Scrubbing Sponge 74N is a dual function cleaning pad. The scrub sponge combines a general purpose scouring pad laminated to an absorbent cellulosic sponge.

Special Features:

Scouring Side:

- Non-rusting and resilient high quality synthetic fibers to provide pad durability and long lasting usage.
- Abrasive minerals selected to provide remarkable scouring for common cleaning jobs.
- Abrasive mineral particles evenly distributed throughout the scouring pad to help ensure effective, consistent, and long lasting performance throughout the life of the pad.
- High quality bonding resin system designed to provide resistance to degradation from exposure to hot water, detergents and normal cleaning liquids.

Applications:

Test in an inconspicuous area prior to use.

Scouring side can be used for cleaning, scouring, and scrubbing cookware, kitchen utensils and equipment, kitchen surfaces, baked-on food, floors, stairways, walls, railings, desks, counters and maintenance equipment.

Sponge side can be used for wiping up spills and messes or carry cleaning solutions to the work surface.

Packaging:

74N: 20 Pads/Case
74NCC: 10 Pads/Pack, 6 Packs/Case

General Use Directions:

The scrub sponge can be used wet or dry.

1. Hold scrub sponge with one hand.
2. Place either side of the scrub sponge against the surface to be cleaned, apply desired pressure and scrub or wipe the area in circular motion.
3. Rinse off scrubbed areas with clean water or wipe off with clean sponge.
4. Clean scrub sponge as necessary after use.

Pad Cleaning Instructions:

Note: Sponge does not require bleaching.

Cleaning scrub sponge provides multiple uses. Used and/or worn-out scrub sponges can be disposed of in regular kitchen trash.

The scrub sponge can be rinsed with warm or hot water or soaked in a cleaning solution to dissolve caked-on soil and grease.

Scrub Sponge Cleaning by Hand

1. Spray or rinse off excess food debris from scrub sponge using a dish sprayer or sink faucet.
2. Wash the scrub sponge in soapy water to remove any remaining food debris and grease. Remove embedded food debris from scrub sponge by hand.
3. Rinse scrub sponge with clean water. Make sure no food debris is left on the pad. Squeeze excess water from the scrub sponge and allow to air dry.

If desired, soak scrub sponge in sanitizer solution. After soaking, squeeze excess solution from the scrub sponge, rinse and allow to air dry.

Scrub Sponge Cleaning by Dishwasher

1. Spray off or rinse excess food debris from scrub sponge using dish sprayer or sink faucet. Remove stubborn food debris such as cheese from scrub sponge by hand.
2. Place scrub sponge in dishwasher and make sure both sides of the pad are exposed to washing.

After washing, take scrub sponge out of dishwasher and allow to air dry.

Product Specifications:

(Typical Values)

1. Size:
Length: 5.9 inches
Width: 3.3 inches
Thickness: 0.70 inch
2. Color:
Scouring Side: Green
Sponge Side: Yellow

Precautionary Summary:

- Do not use scouring side of the scrub sponge on polished or easily scratched surfaces.

3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-2N-20
St. Paul, MN 55144-1000
Order Entry: 800/698-4595
Facsimile: 877/318-0220

CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important Notice to User:

Technical Information: The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty and Limited Remedy: 3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability: Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.



Building and Commercial Services Division

3M Center, Bldg 223-2N-21
St. Paul, MN 55144-1000
www.3M.com/foodservice

Niagara is trademark of 3M Company. Used under license in
Canada.
©3M 2013. All rights reserved.
873748