



Envy[®] Foaming Disinfectant Cleaner

Foaming, quaternary-based, hospital-use disinfectant cleaner that cleans, disinfects and deodorizes in one step.

Features & Benefits

- Ready-to-use foam disinfects in three minutes. It is highly effective against a wide variety of pathogenic microorganisms including bacteria, antibiotic resistant bacteria, viruses, fungi and mildew
- Cleans and disinfects surfaces with a simple spray and wipe. Bactericidal, fungicidal, mildewstatic and virucidal
- Foam dissolves dirt, grime, mold, mildew and other common soils
- Meets OSHA bloodborne pathogen standard for HBV & HIV

Applications

- Use on hard, nonporous surfaces including vinyl, painted surfaces, plastic, glazed ceramic, glazed porcelain, chrome, laminated surfaces and baked enamel surfaces
- Effective on stains in health care, educational, lodging and food service environments





Envy® Foaming Disinfectant Cleaner

Use Instructions

For General Cleaning and/or Deodorizing

- Hold can upright. Spray foam evenly over surface.
- Wipe with clean cloth, sponge or paper towel
- For heavily soiled areas or stubborn spots, let foam stay on surface longer before wiping

For One-Step Cleaning/Disinfecting

- Spray foam evenly over surface. Be sure to wet all surfaces thoroughly.
- Let this product remain on surface for three 3 minutes
- Wipe surfaces to dry and remove any residue, or rinse with potable water as necessary
- A potable water rinse is required for all food contact surfaces

Note: All food contact surfaces such as appliances and kitchen countertops must be rinsed with potable water. Do not use on glassware, utensils, and dishes.

Technical data	Envy® Foaming Disinfectant Cleaner
EPA Reg. No.	70627-35
Color/Form	White, aerosol
pH	12.1
Scent	Lavender
Shelf Life	3 Years

Product	Pack size	Dilution	Product code
Envy® Foaming Disinfectant Cleaner	12 x 19 oz. Aerosol	Ready-to-use	04531. 

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up-to-date shipping information.